

INSTALLATION FOR KITCHEN FAUCETS (3 HOLES & 4 HOLES)

Note:

- Use teflon tape or pipe sealant for threaded connections.
- Do not use plumber's putty, chemical cleaners or any product with ammonia on any of the brass components.
This will cause the finish to tarnish and void the warranty. A non-corrosive 100% silicone is recommended.

1. Carefully remove all parts from the box. This representative Faucet should contain the following:

SPOUT (1) WITH "CENTERBODY" DIVERTER ASSEMBLY (2)
TWO VALVES [HOT (3)] [COLD (4)] COMPLETE WITH HANDLE TRIM (5)
TWO FLEXIBLE HOSES (7)
KITCHEN SIDE HAND SPRAY WITH HOSE (6)
HAND SPRAY BASE WITH LOCK NUT (8)

Note: Some handles do not have top handle lock nuts.

2. Begin by first installing the Spout.

- Remove the "CENTERBODY" Diverter Assembly (2) from the Kitchen Spout (1).
- Drop the Kitchen Spout through the hole in your countertop or sink.
- Re-assemble "CENTERBODY" Diverter Assembly onto bottom of Spout.
- Tighten the Lock Nut against the underside of mounting surface.

3. Identify your Hot and Cold Valves.

- Remove all trim from Valve Assembly (including Top Lock Nut (10) where applicable), leaving Bottom Lock Nut (11).
- Begin to tighten the Valve to your countertop or sink with a Top Lock Nut (10) or Escutcheon (12) (Refer to Diagram) but do not tighten completely.
- Install Escutcheon and Handle (5) on valve body. Be sure that bottom of handle properly clears top of the Escutcheon.
- Once you have adjusted the Valve height, remove Handle and proceed to tighten Valve from the bottom until it is snug.
- Install Handle on the Valve.

4. Connect the two Flex Hoses (7) to the "CENTERBODY" Diverter Assembly and to the HOT and COLD valves respectively. These hoses can be bent or twisted, but be careful not to kink the hoses or you will have limited water supply and excessive noise from the faucet.

5. Installing Hand Spray Base (H-BASE) (8) and Kitchen Side Hand Spray with Hose (6).

- Drop the H-BASE through the hole in your countertop or sink.
- Tighten the Lock Nut against the underside of mounting surface.
- Connect Kitchen Spray hose to the bottom of "CENTERBODY" Diverter Assembly (2), rest the Kitchen Spray on the top of the H-BASE
- This hose can be bent or twisted, but be careful not to kink the hose or you will have limited water supply and excessive noise from the spray.

6. Begin by bleeding the water lines before connecting to the valves. Connect water supplies to bottom of each valve.

7. Remove aerator (24) and flush faucet by running both Hot and Cold water in full open position. Replace the aerator.

8. Check for leaks. If leaks or problems occur, re-tighten all nuts before consulting a plumber.

FOR TECHNICAL SUPPORT PLEASE CALL 718-257-2800

KITCHEN FAUCETS (3 HOLES & 4 HOLES)

INSTALLATION DIAGRAM

