
314-41 GINGER 1LT SMALL (WHITE) PENDANT INSTALLATION INSTRUCTIONS



WARNING

DISCONNECT POWER BEFORE RE-LAMPING OR WIRING THE FIXTURE READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.



This fixtue is supplied with a swivel. By rotating the canopy the fixture may be mounted to angled ceiling.

NOTICE:

CALIFORNIA PROP 65: THIS LIGHTING FIXTURE CONTAINS CHEMICALS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, BIRTH DEFECTS, AND/OR OTHER REPRODUCTIVE HARM. WASH HANDS AFTER USE.

FIXTURE PREPARATION


1. Remove the fixture, parts and parts bag(s) from the carton.

NOTICE:

• Before discarding the carton, double check to make certain that all parts are found.

FIXTURE INSTALLATION

1. Attach the crossbar to the junction box using mounting screw. (The green screw should face the floor). (See FIGURE-01.)



- Determine the overall desired length of the fixture. Assemble the adjustable stems one at a time onto the fixture leads. Tape the end of the leads to a stiff wire (coat hanger) to aid in pulling them through the stems.
- **3.** Remove the threaded ring from the swivel. Fully thread the swivel onto the nipple. Thread the hex nut onto the nipple and the nipple into the crossbar. Place the canopy over the swivel and against the ceiling. Adjust the nipple so that 1/4" of the threads on the swivel extend beyond the canopy. Tighthen the hex nut against the crossbar. Using the threaded ring, install the canopy.
- 4. Unscrew the ring from the swivel. Let the ring and canopy slide down the stem feed the leads and ground wire up through the swivel and the nipple and into the outlet box.
- 5. Fasten the ground wire to the green or bare coppper wire in the juntion box or the green screw on the crossbar.



Approved fastener (wire nut)



Never fasten the ground wire to the black or "hot" wire! Failure to follow this instruction could result in serious injury or death!

Fasten the white fixture lead to the white wire in the Junction Box.
Fasten the wires together with an approved fastener (wire nut).
Starting about 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener.

Make sure that there is no exposed wire or strands that could cause a dangerous short circuit!


- Connect the black fixture lead to the black wire in the Junction Box. Fasten the joined wires as in step 6.
- 8. Lift the canopy and the swivel ring up the stem. Tighten the ring to hold the canopy in place. (See Figure-02)
- 9. Place the lamp into the socket of the fixture.


NOTICE:

This fixture is rated for 60w Type B.

WARNING

- **10.** Carefully thread the glass diffuser through the glas fitter onto the fixture. (SEE FIGURE-02)
- 11. Restore power to the circuit breaker or fuse box.





1	R-VJ36-HRD	MOUNTING HARDWARE
2	R-VJ36-CPY	CANOPY
3	R-VJ36-CAC	SOCKET COVER
4	R-VJ36-ESK	SOCKET
5	R-VJ36-GLS	GLASS
6	R-VJ36-STEM	STEM A