

### **CODE NUMBER**

3790034

### **DESCRIPTION**

3.5 gpf, Dual-Filtered Fixed Bypass Diaphragm, Polished Chrome Finish, Single Flush, Electrical Override, Battery, Sloan® Exposed Sensor Water Closet Flushometer.

#### **DETAILS**

Flush Volume: 3.5 gpf (13.2 Lpf)
Finish: Polished Chrome (CP)
Power Type: Battery

Power Type: BatteryValve: Diaphragm

• Bypass: Dual-Filtered Fixed Bypass Diaphragm (DFB)

Valve Body Material: Semi-red Brass

Fixture Type: Water Closet
 Fixture Connection: Top spud
 Rough-In Dimension: 16" (406mm)
 Spud Coupling: 1 ½" (38mm)
 Supply Pipe: 1" (25mm)

Supply Pipe: 1" (25mm)Override: Electrical (OR)

## **FEATURES**

- 1" I.P.S. Screwdriver Bak-Chek® Angle Stop with Vandal Resistant Stop Cap
- Vacuum Breaker with Flush Connection
- Spud Coupling and Spud Flange for 11/2" Top Spud
- Sweat Solder Adapter with Cover Tube and Cast Wall Flange
- User friendly three (3) second Flush Delay
- No External Volume Adjustment to Ensure Water Conservation
- Stop Seat and Vacuum Breaker Molded from PERMEX® Rubber Compound for Chloramine resistance
- Infrared Sensor with Multiple-focused, Lobular Sensing Fields for high and low target detection
- Engineered Plastic Cover with replaceable Lens Window
- Courtesy Flush® Override Button
- Four (4) Size AA Batteries included

 $\label{thm:permex} \mbox{High Chloramine Resistant PERMEX @ Synthetic Rubber Diaphragm with Linear Filtered Bypass and Vortex Cleansing ActionTM$ 



## **COMPLIANCES & CERTIFICATIONS**







(ADA Compliant, UPC Certified, BAA Compliant)

### RECOMMENDED SPECIFICATION

Valve Body, Cover, Tailpiece and Control Stop shall be in conformance with ASTM Alloy Classification for Semi-Red Brass. Valve shall be in compliance with the applicable sections of ASSE 1037 and ANSI/ASME 112.19.2.

### **VALVE OPERATING PRESSURE (FLOWING)**

15–80 PSI (103–552 kPa). Specific fixtures may require greater minimum flowing pressure - consult manufacturer requirements.

## **DOWNLOADS**

- G2 Optima Plus Installation Instructions
- Control Stop Repair and Maintenance Guide
- Flush Connections Flanges Repair and Maintenance Guide
- Tail Piece Repair and Maintenance Guide
- Sloan Optima Plus Repair and Maintenance Guide
- Additional Downloads

## **NOTES**

All information contained within this document subject to change without notice.

Looking for other variations of the SLOAN 8113 product? View the general spec sheet with all options.

Find a compatible urinal for this flushometer.
Find a compatible water closet for this flushometer.

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com



# **ROUGH-IN**

